

Arm/Disarm with Special Key

Alarm Sounds When Protected Object Is Moved

# ALARM

# PORTABLE

## SECURITY ALARM

HS4332


DIMANGO®

1-YEAR  
WARRANTY

# PORTABLE ALARM

**A multi-purpose  
alarm for baggage  
and personal  
protection.**

- Ultra loud 120dB alarm
- Alarm resets automatically to detect another motion
- Easy selection between baggage and personal alarm
- Portable, easy to take anywhere
- Versatile in applications
- Uses a 9-volt alkaline battery (not included)
- LED for functional applications



### OPERATION

#### Baggage Alarm Mode

After securing alarm to baggage, simply remove round key to activate unit. Once motion is detected, alarm will sound for about a minute before resetting. Insert key to disarm alarm.

#### Personal Alarm Mode

Hold alarm in hand or conceal it in your pocket. Should the need arise to activate alarm, simply pull out the round key. Alarm will stop once the key is inserted (or by removing the battery).

HS4332

DIMANGO®  
PRODUCTS



LAMSON Home Products  
25701 Science Park Drive  
Cleveland, Ohio 44122  
www.lamson-home.com

Made in China  
© 2002 LAMSON & SESSIONS  
0201 SR4332



## INSTRUCTION MANUAL

### Portable Alarm – HS4332

*Congratulations on a wise purchase!*

#### ENCLOSED YOU WILL FIND:

- Alarm
- Square key
- Round key

#### TOOLS NEEDED:

- Small Phillips head screwdriver

#### BATTERY INSTALLATION

1. With both keys in place, remove the screw to the battery compartment.
2. Connect 9-volt alkaline battery onto the appropriate terminals.
3. To test the alarm, give the square key a quarter turn counter-clockwise and remove, then pull out the round key. Alarm will sound.
4. Immediately disarm the unit by inserting the round key.
5. Fit battery assembly into the compartment, replace the cover and then tighten the screw. The Portable Alarm is now ready for use.

#### OPERATION

##### Baggage Alarm Mode

1. Leave the round key in place and secure the Portable Alarm by looping the square key with cord through the baggage handle.
2. Carefully remove the round key which essentially functions as an ON/OFF switch. In this case, upon removal of the round key, there will be an interval of about 9 seconds - sufficient time to release your baggage - after which the alarm may be activated by any sudden movement. Following a delay time of approximately 1.5 seconds, the alarm will sound for about one minute before resetting automatically to detect another motion.

**Note:** A red warning light remains on during the 9 second alarm interval, then re-lights for 1.5 seconds before activation and again to indicate auto-reset function.

3. When retrieving your baggage, you are advised to have the round key in hand to swiftly disarm the Portable Alarm, ideally during the 1.5 second delay before the alarm sounds.

##### Personal Alarm Mode

1. Using the round key only, loop the cord over your wrist and either hold the Portable Alarm in your hand or conceal it in your pocket or bag.
2. Should the need arise to activate the alarm, simply pull out the round key. The alarm can only be silenced by re-inserting the round key (or by removing the battery).

#### Limited Warranty

The product you have purchased is guaranteed against defects in workmanship and materials for the period stated on the package. If the product fails due to a manufacturing defect during normal use, return the product to the store where purchased for replacement OR send product to:

**Lamson Home Products**  
**25701 Science Park Drive**  
**Cleveland, OH 44122 USA**  
**Attn: Customer Service**

**Not Covered** - Batteries, and other expendable items, repair service, adjustment and calibration due to misuse, abuse or negligence are not covered by this warranty. Unauthorized service or modification of the product or of any furnished components will void this warranty in its entirety. This warranty does not include reimbursement for inconvenience, installation, set-up time, loss of use, postage, unauthorized service, or other products used in conjunction with, but are not supplied by, Lamson Home Products.

All requests for replacement must include a **dated sales receipt** (copies accepted) and this guarantee statement. LAMSON HOME PRODUCTS SHALL NOT BE LIABLE FOR LOST PROFITS, INDIRECT, SPECIAL, EXEMPLARY, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING WITHOUT LIMITATION ANY SUCH DAMAGES DUE TO IMPROPER WIRING OR MISUSE OF THE PRODUCT.

#### ALSO AVAILABLE FROM DIMANGO PRODUCTS:

- Extend-A-Chime® – lets you hear your existing wired doorbell in remote areas of your home or yard
- Plug-in and Battery Doorbells and Chimes
- On/Off Remote Switches
- Touch and Automatic Lighting Controls

**DIMANGO**® 



**LAMSON Home Products**  
25701 Science Park Drive  
Cleveland, Ohio 44122  
www.lamson-home.com

Made in China  
0201 IS131